

Batch: A2 Roll No.: 16010322014

Experiment / assignment / tutorial No. 9

Grade: AA / AB / BB / BC / CC / CD / DD

Signature of the Staff In-charge with date

TITLE: To design and simulate waveguide Magic Tee.

AIM: To study isolation and coupling coefficient of a magic Tee


OUTCOME: Analyse microwave passive components for RF measurements.

Design statement: Design and simulate magic tee in the frequency range of 5GHz to 9GHz.

THEORY: - The Magic Tee is a four port device & it is a combination of the E & H plane Tee. If the power is fed into arm 3 (H- arm), the electric field divides equally between arm 1 and 2 with same phase, and no electric field exists in arm 4. If the power is fed in arm 4 (E- arm), it divides equally into arm 1 and 2 but out of phase with no power to arm 3. Further, if the power is fed from arm 1 and 2, it is added in arm 3 (Harm), and it is subtracted in E-arm, i.e., arm 4. The basic parameters to be measured for magic Tee are defined below:
A. Isolation: - The isolation between E and H arms is defined as the ratio of the power supplied by the generator connected to the E-arm (port 4) to the power detected at H-arm (port3) when side arms 1 and 2 are terminated in matched load. Hence, Isolation 3-4 = $10 \log_{10} P_4 / P_3$
B. Coupling Coefficient :- It is defined as $C_{ij} = 10 - / 20$ Where is attenuation / isolation in db when i is input arm and j is output arm. Thus = $10 \log P_i / P_j$ Where P_i is the power delivered to arm i and P_j is power detected at j arm.

ISOLATION: - The isolation between E and H arms is defined as the ratio of the power supplied by the generator connected to the E-arm (port 4) to the power detected at H-arm (port3) when side arms 1 and 2 are terminated in matched load. Hence, Isolation 3-4 = $10 \log_{10} P_4 / P_3$.


COUPLING COEFFICIENT :- It is defined as $C_{ij} = 10 - / 20$ Where is attenuation / isolation in db when i is input arm and j is output arm. Thus = $10 \log P_i / P_j$ Where P_i is the power delivered to arm i and P_j is power detected at j arm.



Observations:


- When input is given from port 1

Power splits between ports 3 and 4,
showing coupling to both H-arm
and E-arm.



- When input is given from port 2

Power divides similarly between ports 3
and 4 but with opposite phase compared
to port 1




School




K. J. Somaiya College of Engineering, Mumbai-77
(A Constituent College of Somaiya Vidyavihar University)

3. When input is given from port 3



4. When input is given from port 4



Attach the screen-shots for all the conditions mentioned above.

Signature of faculty in-charge

Conclusion:

We designed and simulated a magic tee operating within the 5 to 9 GHz frequency range. When power is supplied to arm 3 (the H-arm), the electric field splits evenly between arms 1 and 2, maintaining the same phase, with no electric field present in arm 4. Conversely, when power is fed into arm 4 (the E-arm), it also divides equally between arms 1 and 2, but out of phase, with no power transmitted to arm 3.